

Original 'L' Unit Codes

COOL ❄️ Green	DRY 💧 Red	FAN ⚙️ Red	HEAT ☀️ Amber	Condition
OFF	OFF	OFF	OFF	No power, manual OFF, timed OFF, condensate high level, fault in condensate control
ON	OFF	OFF	OFF	Cooling mode selected
ON	OFF	OFF	FLASHING	AUTO - predominantly Cooling
OFF	OFF	OFF	ON	Heating mode selected
FLASHING	OFF	OFF	ON	AUTO - predominantly Heating
OFF	OFF	ON	OFF	Fan mode selected
OFF	ON	OFF	OFF	Dry mode selected
FLASHING	ON	ON	ON	a. Compressor not running (DX systems only) b. Indoor coil sensor open/short circuit
ON	ON	ON	FLASHING	Outdoor coil sensor (resistor if air conditioner) open/short circuit
OFF	OFF	OFF	FLASHING	Heat pumps only - defrost in progress, indoor fan will stop
FLASHING	OFF	OFF	FLASHING	Heat pumps only - defrost in progress, indoor fan will stop
ON	ON	FLASHING	ON	Room sensor open/short circuit
OFF	OFF	OFF	OFF	De-icing in progress
OFF	OFF	OFF	FLASHING	De-icing in progress

New 'L' Unit Codes

COOL ❄️ Green	DRY 💧 Red	FAN ⚙️ Red	HEAT ☀️ Amber	Condition
OFF	OFF	OFF	OFF	No power, manual OFF, condensate high level, fault in condensate control
ON	OFF	OFF	OFF	Cooling mode selected
ON	OFF	OFF	BLINKS	AUTO - predominantly cooling
OFF	OFF	OFF	ON	Heating mode selected
BLINKS	OFF	OFF	ON	AUTO - predominantly heating
OFF	OFF	ON	OFF	Fan mode selected
OFF	ON	OFF	OFF	Dry mode selected
OFF	OFF	OFF	BLINKS	Outdoor unit defrosting

Diagnostics

Blink x 4	OFF	OFF	OFF	Room sensor missing
Blink x 4	OFF	OFF	OFF	Indoor coil sensor missing
Blink x 4	Blinks	OFF	OFF	Outdoor coil sensor missing
Blink x 1	OFF	Blinks	OFF	Compressor overload
Blink x 2	OFF	Blinks	OFF	Pump fault